

Untitled

... Hardware, Bag 42030305
... Product Manual 42804191
A Base Assy, W/ Wheels 29101089
B BOTTOM PORCELAIN, GLOSS BLUE, ELECTRIC PATIO CADD 29101090
C ASSY, HEATING ELEMENT, ELECTRIC PATIO CADDIE 29101091
D Extension Cord W/ Warning Tag 29101093
E LEG ASSY, CONTROL PANEL, HI-TEMP BLACK, ELECTRIC P 29101529
F LEG ASSY, CART, HI-TEMP BLACK, GAS PATIO CADDIE 29101001
G ASSY, TOP LID, ELECTRIC PATIO CADDIE, BLUE 29101097
H GRILL INSERT, THERMSULATE, TOP LID 29101098
I LID HANDLE, GAS PATIO CADDIE 29101015
J HEAT INDICATOR, GAS PATIO CADDIE 29101016
K Grease Cup Kit 55710171
L Handle, Pull, Front 29101023
M Cooking Grate Porcelain 29101024
N Grill Insert Insulation Bowl, Bottom 29101086
O Top Lid Bracket 29101014